



## Technical Specifications

Physical Properties	Typical Values
Color	Green/White
Solvent	Hydrocarbon, Acetone, Ester, Toluene
Propellant	Ether
Solids Content (min)	35%
Spray Pattern	Web
Coverage	80m <sup>2</sup>
Heat Resistance	90°C
VOC	589 g/l

## Application

Surfaces should be clean, dry and free from grease, oil and dust. Excessive dust will impair performance. Ensure roof surface is clean dry and free of standing water. Any standing water should be removed and the surface left to dry for at least 1 hour before applying adhesive.

Attach a suitable spray nozzle and spray gun.

Connect the hose to the canister and the spray gun to the hose and tighten the connections.

Open the valve on the canister. The valve should remain open until the canister is used up. Use the locking nut on the gun after use. Turning off the valve will result in the adhesive drying in the hose and gun causing blockages.

Hold the spray gun at 90° to the surface and apply a uniform coat of adhesive, to both substrates, ensuring 80- 100% coverage. It is important to remember that TRC BA-708 is a contact adhesive and forms a bond by sticking to itself, so there must be sufficient adhesive on both surfaces for this to happen. Pay particular attention to the edges.

When the adhesive is dry to the touch it is ready for the bond to be made.

Do not allow the adhesive to puddle.

Apply pressure to the surface with a broom or roller to ensure full contact.

Allow solvent to evaporate so that the adhesive is dry to the touch before laying membrane in position. Drying takes approximately two to five minutes depending on substrates, ambient temperature and humidity. Over spraying and pooling of the adhesive will increase drying.

After spraying, remove the spray gun tip and rinse with Solvent Cleaner before it has cured.

Full cure will take 24 hours.

After installation is complete, close the valve and rush of pressure will go through the hose. Pull the trigger on the spray gun to purge adhesive through the system. Remove the spray gun tip and rinse it with Solvent Cleaner before it has cured. If these steps are followed, the system will remain usable for the duration after opening.